




Summary

- OSI Model
- TCP/IP Model
- Encapsulation
- Network Equipment
- Physical link
- IP Protocol & IP Header Format
- IP Address (anatomy, classes, exceptions)
- Subnet




OSI Model







TCP/IP Model





Encapsulation







Network Equipement


- <u>Repeater</u>: electronic device that receives a signal and retransmits it at a higher level or higher power so that the signal can cover longer distances.
- **Bridge**: link between two networks based on the physical addresses.
- <u>Hub</u>: multiport repeater.
- **Switch**: multiport network brige.
- <u>Router</u>: device that forwards data packets between networks.
 based on logical addresses.
- Gateway: used to exit a network. It is based on application data.






Physical Link (1/2)

Coaxial cable



Twisted pair









Physical Link (2/2)

Optic fiber



Serial cable






The IP protocol

- It corresponds to the layer 3of the OSI model (Network)
- Unique identifier, like a phone number
- Used on all network card
- Logical address : allows router to find the reicipient with the IP address





IP Header





IP Address (1/2)

- It is 32 bits long:
 - Decimale notation: 192.168.0.1
 - Hexadecimale notation: 0xC0A80001
- Link to a network access point, not to a host
- An host can be on several networks
- Each access point must have a unique IP address on a network




IP Address (2/2)

- An IP address consists of two parts
 - o Host id:
 - Assigned by the network administrator
 - Identifies a Host on a network
 - O Network id :
 - Assigned by the authorities
 - Identifies the network
- The size of the network id depends on the class.





IP class (1/2)







IP classes (2/2)

A Class

- 8 bits for network id
- 24 bits for host id
- Range: 10.0.0.0 to 127.0.0.0
- 254³ possible addresses

• C Class

- 24 bits for network id
- 8 bits for host id
- Range: 192.0.0.0 to 223.255.255.255
- 254 possible addresses

• B Class

- 16 bits for network id
- 16 bits for host id
- Range: 128.0.0.0 to 191.255.0.0
- 254² possible addresses

D Class

- Multicast adresses used for the stream of audio-video data
- Range: 224.0.0.0 to 239.255.255.255



Private addresses

- A Class
 - 10.0.0.0 to 10.255.255.255 (10.X.X.X/8)
- B Class
 - 172.16.0.0 to 172.31.255.255 (172.16.X.X/16)
- C Class
 - 192.168.0.0 to 192.168.255.255 (192.168.X.X/24)



Special Address

Network address

- All of the host id bits are 0;
- Example : 163.5.0.0 (For a B class).

Broadcast address

- Contact address for all the machines on the same network;
- All of the host id bits are 1;
- Example : 163.5.255.255 (For a B class).





Subnet

- They are used to cut a network into several parts
- Thet reduce the broadcast domain
- Subnets addresses are created from bits of the host part
- The size of a subnet depends on the number of host that will be present on the network.



The subnet mask

- It is necessary to know the boundary between the host id and network id
- It has the same form as an IP address:
 - o 1 bits for the network id
 - o 0 bits for the host id
- Example :

o C Class: 192.168.0.1


Subnet mask: 255.255.255.0





Practical work (1/2)

• Straight cables are used to connect PCs to a hub or network switch for example.







Practical work (2/2)

• Crossover cables are used to connect two PCs for example.

